# TLC Tugger Sizing Guide

Print at 100% / Actual Size. Check the scale bar at the bottom before you cut.

**1.** Cut out each circle. Tip: fold along the dotted line and snip from the fold.

**2.** While soft, pull any loose skin back behind your glans (the head).

**3.** Find your **Good Fit line**: about 1/3 to 1/2 of the way down your glans. That is where your TLC Tugger body sits.

**4.** Starting with the smallest circle, push your glans into each one:

- Stops **above** your Good Fit line? Too small, go up a size.
- Slides **past** your Good Fit line? Too big.
- Snug **right at** your Good Fit line? **That's your size!**

**5.** Between two sizes? Choose the smaller one.




**F**
26 mm · SR 6 · contact us

**G**
28 mm · SR 8

**H**
30 mm · SR 10

**I**
32 mm · SR 12

**J**
34 mm · SR 14

**K**
36 mm · SR 16

**L**
38 mm · SR 18

**M**
40 mm · SR 20 · contact us

Each circle is the **actual size** of that TLC Tugger body. We make sizes G to L. Measured an F or M? Reach out at **tlctugger.com/contact-us**

## Next: choose your length

Your size sets the width. Your coverage sets the length. **Find your FCI** to see which body length (+0 to +30mm) fits you best.

## Pair it with the right cone

Every **TLC Tugger Kit** and **VLC Kit** comes with the standard Your-Skin Cone for your size. Our How to Measure page has a cone chart for a comfort or snug fit, and for replacements.

More sizing help: **tlctugger.com/how-to-measure**

**Scale check: this bar = 1 inch (2.54 cm)**

